

# Point Of Sale Standees

## Assembly Guide



**Step 1:** Unpack the Strut and lay it flat on a table. If you have a 1400mm high Strut, you may need to unfold it.



**Step 2:** Fold the side panels of the Strut in where the Half Cuts are with two hands.



**Step 3:** Stand the Strut upright and fold the small locking panel in where the Half Cut is. The panel(s) should lock comfortably in place between the concave curve.



**Step 4:** Your Strut should now be assembled like one of the above sizes. Note: your Strut size will be automatically chosen for you according to the height of your Standee for the best fit.



**Step 5:** To attach the Strut to your Standee, simply hold both objects upright and align the hook and loop velcro to the allocated sections. **It is important to align the base of your Standee and Strut so they balance upright.**



**Step 6:** Enjoy your beautiful custom POS Standee!